
466077 rev01





Read through <u>ALL</u> instructions before commencing installation. If you have any questions about this product or issues with installation contact the customer services help line before returning this product to the store.

+44 (0) 333 320 0463 (UK) 1-800 667 0808 (USA) 50kg 110lbs


AVF Group Ltd. Hortonwood 30, Telford, Shropshire, TF1 7YE, England AVF Group, Inc. 2775 Broadway, Cheektowaga, Buffalo, New York, 14227 USA www.avfgroup.com

Assembly Overview




2 Person Installation Recommended


Determine TV and Cornermount position




Fit Shelves




Fit Support Arm Assembly






Tools Recommended





	Index
1	Measure the TV fixing holes Width and Height
2	Fitting the TV Brackets
3	Determine TV and Cornermount position
4	Determine TV and Cornermount Height
5	Fitting the Support Arm Assembly
6	Fitting the TV Bracket
7	Assembling Shelf Module
8	Connecting Shelf Module
9	Connecting the TV
10	Levelling Shelves
11	Adjusting Shelf Height
12	Fitting the Bracket Cover
Retain all packaging in case the bracket needs to be returned.	

Contents may vary from photography/ Illustrations.
You will not need all these parts, so expect there to be some left over depending upon the specification of your TV. This product is intended for indoor use only. Use of this product outdoors could lead to failure and personal injury. It is the responsibility of the installer to ensure that the mounting wall is of a suitable standard and void of any services (eg gas, electricity, water etc).

AVF accept no responsibility for any damage or loss caused by installing this product in a sub standard wall.










If width (X) is greater than 600mm or height (Y) greater than 400mm STOP installation now and contact the customer help line



You are provided with 4 diameters of TV fixing screws, M4, M5, M6 and M8. Determine the screw diameter that fits and remember for step 2.


Fitting the TV Brackets


No Spacers

For TVs with flat / unobstructed back

W1/W2 **Spacers**


For TVs with irregular / obstructed back








WARNING


U5-**U**7












Attach the bracket to the back of your TV using suitable screw, reducer and spacer combinations.




Use templates PT1, PT2 and PT3 to help you position your TV and Cornermount accurately.




























Extend **PT**₁ and **PT**₂ until they make contact with the wall.


Please note: You can only attach your Cornermount to Solid Wall or Wood Stud Wall. If you are attaching to Wood Stud Wall the location of the wood studs will determine where you can position PT₂ and PT₂.


If you have PT1 and PT2 at max extension it is possible you will see some of the Support Arm Assembly when you view your TV, however, you will have more movement. If you have PT1 and PT2 at min extension it is possible you will not see any of the Support Arm Assembly when you view your TV, however, you will have less movement. Please consider this when positioning PT1 and PT2.

The diagram below shows how the ends of PT1 and PT2 must make contact with the wall.




You can turn **PT**² 180° and flip **PT**¹ over so that your TV can move further in another direction. The example shows how you can get extra movement to the left by swapping **PT**¹ and **PT**².







Turn and slide template **PT3** to see that there are no clashes. Always ensure hole is inside slot, see step **iv**.






Once you have decided on the position of your TV and Cornermount tape PT₁, PT₂ and PT₃ together.

Mark the wall where PT₁ and

Mark the wall where PT₁ and PT₂ touch the wall using the lines as a guide.




Determine TV and Cornermount Height






Decide how high you want the bottom of your TV to be from the floor (dimension a).

At this point you will need to take into consideration if you are using 1 or 2 shelves as this will affect how high the bottom of your TV can be from the floor.





Measure from the bottom of bracket **B2** to the bottom of your TV (dimension)






Complete the sum to get dimension



+ 364 =

* Minimum dimension = 1000mm 1 shelf Minimum dimension = 1150mm 2 shelves










Fitting the support arm assembly takes 8 steps. Follow the 8 steps to ensure your support arm assembly is square and level.





Position the top hole of bracket H over drill point you made in step 4, and mark the bottom drill point






































You can build your shelf module as either 1 shelf or 2 shelves. Please follow the suitable assembly.




2 Shelf Assembly




















Slide

