


466525 Rev05

Please read these instructions thoroughly before installation.



If you have any questions or need
spare parts don't worry, we're happy to help.

Customer Helpline

0333 320 0463


Helpline Open Mon to Thurs 9am - 5pm, Fri 9am - 4pm

Online Support


www.avfgroup.com/support

Assembly Overview


Fit the TV Mounting Plate




Fit the Wall Bracket



Connect the TV



Suitable Wall Types



Solid Wall




Wood Stud


Tools Recommended








Stud Finder



Ø10mm (25/64")
Masonry



Ø3mm (1/8")
Wood



Index

1 Measure the TV fixing holes Width and Height

2 Preparing the TV Mounting Plate

3 Fitting the TV Mounting Plate

4 Fitting the Wall Bracket

5 Assemble the Bracket

6 Fitting the Wall Covers

7 Connecting the TV

Retain all packaging in case the product needs to be returned.

Contents may vary from photography / illustrations.


You will not need all these parts, so expect there to be some left over depending upon the specification of your TV.

This product is intended for indoor use only. Use of this product outdoors could lead to failure and personal injury.


It is the responsibility of the installer to ensure that the mounting wall is of a suitable standard and void of any services (eg gas, electricity, water etc).

AVF accept no responsibility for any damage or loss caused by installing this product in a substandard wall.


Boxed Parts




TV Screws, Reducers and Spacers



1 Measure the TV fixing holes Width and Height



If width (X) is greater than 200mm or height (Y) greater than 200mm STOP installation now and contact the customer help line.



M4 =	Q1/Q2
M6 =	Q3/Q4
M8 =	Q5/Q6/Q7

You are provided with 3 diameters of TV fixing screws: **M4**, **M6** and **M8**. Determine the screw diameter that fits and remember for step 3

2 Preparing the TV Mounting Plate

Use the option that fits your TV.

OPTION 1

- (X) 50mm x (Y) 50mm
- (X) 75mm x (Y) 75mm
- (X) 100mm x (Y) 100mm

OPTION 2


- (X) 100mm x (Y) 200mm
- (X) 200mm x (Y) 100mm

OPTION 3

- (X) 200mm x (Y) 200mm



If in any doubt please call the customer helpline.

OPTION 1




If your TV fixing holes match any of the sizes shown above you will not need to use any adaptors. Please go to step 3.

OPTION 2





OPTION 3



Example shown is 200 x 200 fixings

Top




M x8 **N** x8

3 Fitting the TV Mounting Plate


No Spacers

For TVs with flat / unobstructed back.




Spacers **P1/P2**

For TVs with irregular / obstructed back.




WARNING




After completing step 3 you will have fixings left over, please keep for future reference.

OPTION 1





OPTION 2 & 3






4 Fitting the Wall Bracket

Solid Wall





Remove Dust from Hole.

Wood Stud



Ensure bracket is in the centre of the wood stud








Lubricate screw thread with soap.



DO NOT overtighten screws.
Tighten screws by hand only.

R x3 **S** x3



Lubricate screw thread with soap.

DO NOT overtighten screws.
Tighten screws by hand only.



DO NOT use wall plugs in a wood stud wall.



R x3




5 Assemble the Bracket




6 Fitting the Wall Covers

i




B1

ii




Carefully bend apart the 2 highlighted sections shown above and then slide into position

iii



B2


iv






Carefully bend apart the 2 highlighted sections shown above and then slide into position

7 Connecting the TV

Attach TV




TV Locking




Optional

Lock tilt



TV Levelling



Storing the Allen Key

