

60kg
132lbs



Read through **ALL** instructions before commencing installation.


If you have any questions about this product or issues with installation, contact the customer services helpline before returning this product to the store.

This TV Wall Mount is intended for use with televisions weighing **Maximum 60kg (150lbs)**. Use with products heavier than maximum weights may result in instability causing possible injury.


CUSTOMER SERVICES HELPLINE NUMBER: **0333 320 0463 (UK)**

Assembly Overview


Fit the TV Mounting Plate




Determine your TV position




Fit the Wall Plate




Connect the TV



Suitable Wall Types



Solid Wall



Wood Stud

Index

1 Measure the TV fixing holes Width and Height

2 Preparing the TV Mounting Plate

3 Fitting the TV Mounting Plate

4 Marking Wall for Drill Points

5 Fitting the Wall Bracket

6 Fitting the Wall Bracket Covers

7 Connecting the TV

8 Lock Tilt (optional)

9 TV Levelling

Retain all packaging in case the product needs to be returned.

Contents may vary from photography / illustrations.

You will not need all these parts, so expect there to be some left over depending upon the specification of your TV.

This product is intended for indoor use only. Use of this product outdoors could lead to failure and personal injury.


It is the responsibility of the installer to ensure that the mounting wall is of a suitable standard and void of any services (eg gas, electricity, water etc).

AVF accept no responsibility for any damage or loss caused by installing this product in a substandard wall.



Tools Recommended



Stud Finder




10mm
13mm




Ø5mm (13/64")
Wood



Ø12mm (15/32")
Masonry




Boxed Parts




C1



C2



A



B

x4

TV Screws, Reducers and Spacers



H1 x4



H2 x4



I1 x12




I2 x4




M4

J1 x4




M4

J2 x4




M4

J3 x4




M5

J4 x4




M6

J5 x4




M6

J6 x4




M6

J7 x4




M8

J8 x4




M8

J9 x4



M8

J10 x4



WT



D x4



M6

F x8




E x8




M6


G x16



K x3




L x3

1**Measure the TV fixing holes Width and Height**

If width (X) is greater than 600mm or height (Y) greater than 400mm
STOP installation now and contact the customer helpline

You are provided with 4 diameters of TV fixing screws, **M4**, **M5**, **M6** and **M8**.
Determine the screw diameter that fits and remember for step 3.



M4 = J1/J2/J3

M5 = J4


M6 = J5/J6/J7

M8 = J8/J9/J10

After completing step 3 you will have fixings left over, please keep for future reference.

2 Preparing the TV Mounting Plate

Before you can attach the TV mounting plate to your TV you need to remove the plate from your wall mount.



i Remove the Level Lock Screw and Washer and safely keep for step 7.

ii Remove the TV Mounting Plate.

Use the option that fits your TV

OPTION 1

X

75mm x

Y

75mm

X

100mm x

Y

100mm

X

100mm x

Y

200mm

X

200mm x

Y

100mm

X

200mm x

Y

200mm

OPTION 2

X

300mm x

Y

100mm

X

300mm x

Y

200mm

X

300mm x

Y

300mm

X

400mm x

Y

100mm

X

400mm x

Y

200mm

X

400mm x

Y

300mm

X

400mm x

Y

400mm

X

75-400mm x

Y

75-400mm

X

600mm x

Y

100mm

X

600mm x

Y

200mm

X

600mm x

Y

300mm

X

600mm x

Y

400mm

X

400-600mm x

Y

75-400mm

X


630mm x

Y

310mm

If in any doubt please call the customer helpline

OPTION 1




If your TV fixing holes match any of the sizes shown above you will not need to use any adaptors. Please go to step 3.


OPTION 2




When attaching adaptors **B** you must always use **HOLES x4** and either of the **SLOTS**.




Example shown is 600 x 400 fixings.









Adaptors **B** can be fixed in different positions in the slots on the plate to match your TV fixing holes.



Below are some common examples of how the adaptors can be positioned to match the fixing holes on your TV.




3

Fitting the TV Mounting Plate

No Spacers




For TVs with flat / unobstructed back.







Spacers

1/12

For TVs with irregular / obstructed back.





WARNING



If your TV has an irregular/obstructed back or if you have any issues fitting to the back of your TV with the supplied screws, please call the customer services helpline.

Before you fully tighten the TV mounting plate check that the mounting plate holes line up with the fixing holes on the back of your TV.



J1 - J10

| | | | |
|----|---------|---------|----------|
| | J1 - J3 | J4 - J7 | J8 - J10 |
| H2 | ✓ | ✗ | ✗ |
| H1 | ✓ | ✓ | ✗ |

Do you need I1 or I2?

I2

I1

If required


Attach the mounting plate to the back of your TV using suitable screw, reducer and spacer combinations.

4

Marking Wall for Drill Points



For this step you will need your Wall Marking Template **WT**.





To determine the exact position for your drill points use the Height Calculator app. Follow the link to the app shown on your Wall Marking Template.

Before marking any drill points you will need to determine the wall type that you have, either **Solid Wall** or **Wood Stud Wall**. Ensure the drilling area is free from mains services (Gas / Electric / Water).

If fixing to a wood stud wall you must place the drilling template so that the drilling holes are in the centre of the wood stud.



Before you drill make sure you are happy with the position and ensure the holes are level.

Solid Wall




Remove Dust from Hole.

Wood Stud




Ensure you drill in the centre of the wood stud





K

L



K x3


L x3



Lubricate screw thread with soap.



DO NOT overtighten screws.
Tighten screws by hand only



K



K x3









Lubricate screw thread with soap.




DO NOT overtighten screws.
Tighten screws by hand only


6 Fitting the Wall Bracket Covers




D x4



8 Lock Tilt (optional)



9 TV Levelling



Loosen the Level Lock Screw, adjust your TV until it is level, then re-tighten the screw.