

20kg
44lb



Read through ALL instructions before commencing installation.


If you have any questions about this product or issues with installation, contact the customer services helpline before returning this product to the store.

This TV Wall Mount is intended for use with televisions weighing **Maximum 20kg (44lbs)**. Use with products heavier than maximum weight may result in instability causing possible injury.


CUSTOMER SERVICES HELPLINE NUMBER: 0333 320 0463 (UK)

Assembly Overview


Fit the TV Mounting Plate




Fit the Wall Bracket



Hang the TV



Suitable Wall Types



Solid Wall



Wood Stud


Tools Recommended








Stud Finder



Ø10mm (25/64")
Masonry



Ø3mm (1/8")
Wood



Index

1 Measure the TV fixing holes Width and Height

2 Preparing the TV Mounting Plate

3 Fitting the TV Mounting Plate

4 Fitting the Wall Bracket

5 Hanging the TV

Retain all packaging in case the product needs to be returned.

Contents may vary from photography / illustrations.






You will not need all these parts, so expect there to be some left over depending upon the specification of your TV.

This product is intended for indoor use only. Use of this product outdoors could lead to failure and personal injury.

It is the responsibility of the installer to ensure that the mounting wall is of a suitable standard and void of any services (eg gas, electricity, water etc).

AVF accept no responsibility for any damage or loss caused by installing this product in a substandard wall.

Boxed Parts



H x8

J x8

N x2

O x2

TV Screws, Reducers and Spacers



L1 x4



L2 x4



M1 x4




M2 x4




M4

K1 x4




M4

K2 x4




M6

K3 x4




M6

K4 x4




M8

K5 x4




M8

K6 x4




WT

1 Measure the TV fixing holes Width and Height



If width (X) is greater than 200mm or height (Y) greater than 200mm
STOP installation now and contact the customer help line.



You are provided with 3 diameters of TV fixing screws **M4**, **M6** and **M8**.
Determine the screw diameter that fits and remember for step 3

2 Preparing the TV Mounting Plate

Use the option that fits your TV.

OPTION 1

- (X) 50mm x (Y) 50mm
- (X) 75mm x (Y) 75mm
- (X) 100mm x (Y) 100mm

OPTION 2


- (X) 100mm x (Y) 200mm
- (X) 200mm x (Y) 100mm

OPTION 3



- (X) 200mm x (Y) 200mm

If in any doubt please call the customer helpline.


OPTION 1



OPTION 2





OPTION 3



Example shown is 200 x 200 fixings

Top




H x8 **J** x8

3 Fitting the TV Mounting Plate


No Spacers

For TVs with flat / unobstructed back.




Spacers **M1/M2**

For TVs with irregular / obstructed back.




WARNING




After completing step 3 you will have fittings left over, please keep for future reference.

Attach the TV Mounting Plate to the back of your TV using suitable screw, reducer and spacer combinations.

OPTION 1





OPTION 2 & 3





4 Fitting the Wall Bracket

Solid Wall






Remove Dust from Hole.

Wood Stud




Ensure bracket is in the centre of the wood stud



Lubricate screw thread with soap.



DO NOT overtighten screws.
Tighten screws by hand only.




Lubricate screw thread with soap.



DO NOT overtighten screws.
Tighten screws by hand only.

5 Hanging the TV



Hold the TV parallel to the wall. Offer the white bush towards the centre of the wall bracket and lower into position. Ensure both the white bush and locating plate securely engage with the wall bracket. When the white bush is in the horizontal slot your TV is secured.

To remove the TV, rotate TV counter clockwise as far as possible and then lift vertically.

TV Levelling (optional)

Adjust the levelling resistance, if necessary, by tightening or loosening the screw in the white bush.



Gently adjust in small increments. DO NOT overtighten.

