

2

Top
Parte Superior

A_{x4}
M4 x 16mm

B_{x4}
M5 x 16mm

C_{x4}
M6 x 16mm

D_{x4}
M8 x 16mm

E_{x4}
M5

F_{x4}
M6

G_{x4}

TV

A+E
B+E
C+F
D

A+E+G
B+E+G
C+F+G
D+G

3

65mm (2 9/16")

Remove dust from hole
Elimine el polvo del agujero

✓

✗

Ø8mm (5/16")

F_{x2}

H_{x2}

I_{x2}

Lubricate screw thread with soap
Lubrique la rosca del tornillo con jabón

3

50mm (2")

X

Ensure bracket is in the centre of the wood stud
Asegúrese de que el soporte está en el centro de la viga de madera

Ø3mm (1/8")

F_{x2}

M6

H_{x2}

Lubricate screw thread with soap
Lubrique la rosca del tornillo con jabón

4

i

ii

Click!

The diagram illustrates the installation of a door panel. It is divided into two parts, labeled 'i' and 'ii'. In part 'i', a door panel is shown being aligned with a vertical wall. A circular inset shows a close-up of the panel's edge fitting into a slot on the wall. In part 'ii', the panel is shown fully attached to the wall. A circular inset shows a close-up of the panel's edge locking into the wall's slot, with the word 'Click!' indicating the sound of the panel locking into place.