

2

Measure the TV fixing holes Width and Height

Option 1

100mm

75mm

100mm

75mm

+

Ø8mm (5/16")

U2x8

M5 10mm

U3x8

M5

If Using Adapters **U1**

Option 2

200mm

100mm

+

Ø8mm (5/16")

U2x8

M5 10mm

U3x8

M5

Option 3

200mm

200mm

+

Ø8mm (5/16")

U2x8

M5 10mm

U3x8

M5

3

Top

Haut

Parte Superior

T12x8

T11x4

T1x4

M4 16mm

T2x4

M4 30mm

T3x4

M5 16mm

T4x4

M5 30mm

T5x4

M6 16mm

T6x4

M6 30mm

T7x4

M8 16mm

T8x4

M8 30mm

T9x4

M5

T10x4

M6

✗

TV

✓

T1/T2

T9

T3/T4

T9

T5/T6

T10

T7/T8

If required
Si nécessaire
Si se requiere

T12

and / or

T11

4

Solid Wall

✓

✗

i

12.5mm (½") Max

65mm (2 9/16")

ii

Remove dust from hole

iii

W1x2

W2x2

+

Ø8mm (5/16")

4

Wood Stud

✓

✗

i

12.5mm (½") Max

50mm (2")

ii

Ensure bracket is in the centre of the wood stud

iii

W1x2

+

Ø3mm (1/8")

Lubricate screw thread with soap