

Retain all packaging in case the bracket needs to be returned.

Contents may vary from photography/ illustrations.


You will not need all these parts, so expect there to be some left over depending upon the specification of your TV.

This product is intended for indoor use only. Use of this product outdoors could lead to failure and personal injury.

It is the responsibility of the installer to ensure that the mounting wall is of a suitable standard and void of any services (eg gas, electricity, water etc).

Crown AV accept no responsibility for any damage or loss caused by installing this product in a sub standard wall.

Periodically check all nuts and bolts are tight.



MTC600


463694 rev01

70"

178cm

132lbs

60kg



Read through **ALL** instructions before commencing assembly.




If you have any questions about this product or issues with assembly contact the customer help line before returning this product to the store.






Crown AV, PO Box 342,  
Telford, TF1 9DU, UK

Customer Help Line  
**01952 678859**




[www.crownav.co.uk](http://www.crownav.co.uk)





Step 2



Step 3





Remove dust from hole




Lubricate screw thread with soap




Step 3



Ensure bracket is in the centre of the wood stud



Lubricate screw thread with soap



Step 4

