



Read through <u>ALL</u> instructions before commencing installation. If you have any questions about this product or issues with installation contact the customer services help line before returning this product to the store. Visit http://te.avf.co.uk/p/nul201 for more information.


CUSTOMER SERVICES HELP LINE NUMBER:

01952 670009





Assembly Overview



Index

- Measure the TV fixing holes Width and Height
- Preparing the TV Mounting Plate
- Fitting the TV Mounting Plate
- Fitting the Wall Bracket
- **5** Attach the TV

Retain all packaging in case the bracket needs to be returned.


Contents may vary from photography/ Illustrations.

You will not need all these parts, so expect there to be some left over depending upon the specification of your TV.


This product is intended for indoor use only. Use of this product outdoors could lead to failure and personal injury.


It is the responsibility of the installer to ensure that the mounting wall is of a suitable standard and void of any services (eg gas, electricity, water etc). AVF accept no responsibility for any damage or loss caused by installing this product in a sub standard wall.


Tools Recommended




Boxed Parts












If width (X) is greater than 200mm or height (Y) greater than 200mm STOP installation now and contact the customer help line

You are provided with 4 diameters of TV fixing screws, **M4**, **M5**, **M6** and **M8**. Determine the screw diameter that fits and remember for step 3.



Preparing the TV Mounting Plate

Use the option that fits your TV

OPTION 1

TV Fixing Hole Sizes

X 75mm x **Y** 75mm

(X) 100mm x **(Y)** 100mm


OPTION 2

TV Fixing Hole Sizes


X 200mm x **Y** 100mm - 200mm

If in any doubt please call the customer help line.


OPTION 1




OPTION 2




3 Fitting the TV Mounting Plate




Attach the bracket to the back of your TV using suitable screw, and reducer combinations.



After completing step 3 you will have fittings left over, please keep for future reference




4




5 A

Attach the TV

Attaching



TV Levelling



Optional

Lock Tilt

