


NUL401


Leaflet No. **464050** rev00



Read through ALL instructions before commencing installation.
If you have any questions about this product or issues with installation contact the customer services help line before returning this product to the store. Visit <http://te.avf.co.uk/p/nul401> for more information.

CUSTOMER SERVICES HELP LINE NUMBER:


01952 670009




AVF Group Ltd. Hortonwood 30, Telford, Shropshire, TF1 7YE, England

Assembly Overview


Fit the TV Mounting Plate



Fit the Wall Bracket



Attach the TV



Index

1 Measure the TV fixing holes Width and Height

2 Preparing the TV Mounting Plate

3 Fitting the TV Mounting Plate

4 Fitting the Wall Bracket

5 Attach the TV

Retain all packaging in case the bracket needs to be returned.

Contents may vary from photography/ Illustrations.


You will not need all these parts, so expect there to be some left over depending upon the specification of your TV.

This product is intended for indoor use only. Use of this product outdoors could lead to failure and personal injury.


It is the responsibility of the installer to ensure that the mounting wall is of a suitable standard and void of any services (eg gas, electricity, water etc).

AVF accept no responsibility for any damage or loss caused by installing this product in a sub standard wall.




Tools Recommended



Boxed Parts




TV Screws, Reducers and Spacers




1

Measure the TV fixing holes Width and Height



If width (X) is greater than 400mm or height (Y) greater than 400mm
STOP installation now and contact the customer help line

You are provided with 3 diameters of TV fixing screws, **M4**, **M6** and **M8**.
Determine the screw diameter that fits and remember for step 3.



M4 = G1-G4

M6 = G5-G8

M8 = G9-G12

Preparing the TV Mounting Plate

Use the option that fits your TV

OPTION 1

TV Fixing Hole Sizes

- ☒ 75mm x ☐ 75mm
☒ 100mm x ☐ 100mm
☒ 200mm x ☐ 100mm
☒ 200mm x ☐ 200mm

OPTION 2

TV Fixing Hole Sizes

- ☒ 300mm x ☐ 200mm
☒ 300mm x ☐ 300mm
☒ 400mm x ☐ 200mm
☒ 400mm x ☐ 300mm




OPTION 3

TV Fixing Hole Sizes

- ⓧ 400mm x Ⓨ 400mm


This bracket is not limited to the TV fixing sizes above. If your TV has fixing holes that do not match the sizes above use the **X** and **Y** dimensions shown in the diagrams to determine the correct option layout for your TV. If in any doubt please call the customer help line.

OPTION 1





M5



F | x4



OPTION 2



OPTION 3




3

Fitting the TV Mounting Plate

No Spacers


For Tvs with flat/unobstructed back




Spacers

I1-I3

For Tvs with irregular/obstructed back




WARNING




After completing step 3 you will have fittings left over, please keep for future reference


OPTION 1



OPTION 2 & 3



* Screw diameter dependant




Attach the bracket to the back of your TV using suitable screw, reducer and spacer combinations.

4


Fitting the Wall Bracket

Solid Wall


i



ii




Remove dust
from hole





Wood Stud

i







ii



Ensure bracket is
in the centre of
the wood stud






DO NOT over tighten screws
Tighten screws by hand only



J x3


K x3



DO NOT over tighten screws
Tighten screws by hand only




J x3




5

Attach the TV

Attaching



TV Levelling



Optional

Lock Tilt



L x2

