

40kg  
88lbs



Read through ALL instructions before commencing installation.

Please don't return me to the store

If you are unsure or need advice  
please contact our support team:

0333 320 0463 or [avfgroup.com](http://avfgroup.com)

Phone lines open Mon-Fri during AVF office hours



**IMPORTANT INFORMATION!**

We advise that before starting the assembly of this product that you familiarise yourself with the instructions and the parts list in this leaflet.


**Do not's**

- Do not over tighten any part of this assembly.
- Do not place hot or cold objects on to or next to any glass surface unless the object is sufficiently insulated to prevent contact.
- Do not strike the glass with hard or pointed items.
- Do not sit or stand upon horizontal glass surfaces.
- Do not use washing powders or other substances containing abrasives when cleaning the glass.

**Do's**


- Do use a damp cloth with diluted washing up liquid for cleaning the glass surfaces.
- Check all nuts and bolts from time to time.

**Maximum TV weight and shelf capacities**




**WARNING:** Wherever possible distribute weight evenly.




**TV Screws, Reducers and Spacers**



# Boxed Parts



# Tools Recommended



**J**  
x2




**K**  
x2



**L**  
x4




**M**  
x4




**N**  
x6




**O**  
x4




**P**  
x2



**Q**  
x4




**R**  
x2




**S**  
x1



**T**  
x6





**U**  
x2



**V**  
x2

1

## Measure the TV fixing holes Width and Height



**M4 = TV1-2**

**M5 = TV3-4**

**M6 = TV5-6**

**M8 = TV7-8**




If width ⓧ is greater than 660 mm or height Ⓨ greater than 400 mm **STOP** installation now and contact the customer help line.

You are provided with 4 diameters of TV fixing screws, **M4**, **M5**, **M6** and **M8**. Determine the screw diameter that fits and remember for step 9.

2




Put a piece of material underneath the glass to prevent damage




3

D




4





5



Hand Tighten Only




6








Please consider the size of your TV before fixing plate G. See Below for guide.



Recommended for Medium to Large TV.



Recommended for Large to Extra Large TV.




**M**  
x4

**Q**  
x4





M6

**T**  
x4




**S**  
x1










**No Spacers**


For TVs with flat / unobstructed back.

**Spacers****SP1/SP2**


For TVs with irregular / obstructed back.

**WARNING**

After completing step 2 you will have fittings left over, please keep for future reference.



Attach the bracket to the back of your TV using suitable screw, reducer and spacer combinations.



To remove TV

