

## Tools Recommended

## IF YOU ARE IN ANY DOUBT, CONSULT A QUALIFIED CONTRACTOR

Periodically check all nuts and bolts are tight.

standard wall.

TESCO accept no responsibility for any damage or loss caused by installing this product in a sub void of any services (eg gas, electricity, water etc).

It is the responsibility of the installer to ensure that the mounting wall is of a suitable standard and ensure the product is correctly installed.


This product is sold as a home DIY product and as such, it is the responsibility of the installer to personal injury.

This product is intended for indoor use only. Use of this product outdoors could lead to failure and VT ruoy fo noitscification of your TV.


You will not need all these parts, so expect there to be some left over depending upon the Contents may vary from photography/ Illustrations.

Retain all packaging in case the bracket needs to be returned.


**466323** rev00



selod gnixif VT ett et selod  $(\Gamma)$ 



TC3





Read the operating instructions and keep them in a safe place. If you have any questions about this product or issues with installation contact the help line before returning this product to the store.

## Help Line: **0333 320 8027**

Monday - Thursday 08:30 - 17:00 Friday 08:30 - 16:00 Calls charged at local rate













When deciding which screw diameter and length is suitable for your TV it is important to STOP immediately as soon as you feel any resistance to prevent damage to your TV



You are provided with 3 diameters of TV fixing screws, M4, M6 and M8. Determine the screw diameter that fits and remember for the next step







Do I need to use spacers D ?


Spacers are provided so that you can achieve the correct fit between the back of your TV and Mounting Plate, please see below for examples of when spacers are required

No TV has flat back and flush fixing holes











Maybe







(3) Fitting the TV Mounting Plate

B1 or B2 only required for certain screws

C1 or C2 C3 or C4

**C5** or **C6** 


**D** x1 or x2 if required

**C2** M4 30mm

M6 12mm

**C1** M4 12mm

 $(\mathbf{4})$  Wood Stud






**9** 

**C5** M8 12mm

**C6** M8 30mm

Ø3mm

**C4** M6 30mm









Lubricate screw thread with soap



Remove dust from hole









Do not use  ${\bf F}$  wall plugs in wood stud



Tighten with hand tools only

