
jl.avfgroup.com

466522 rev01

JGL200










Read through <u>ALL</u> instructions before commencing installation.

If you have any questions about this product or issues with installation, contact the customer services help line before returning this product to the store.

CUSTOMER SERVICES HELP LINE NUMBER: 0333 320 0463







Index

- Measure the TV fixing holes Width and Height
- Preparing the TV Mounting Plate
- **3** Fitting the TV Mounting Plate
- 4. Fitting the Wall Bracket
- Connecting the TV

Retain all packaging in case the bracket needs to be returned.

Contents may vary from photography/ Illustrations.


You will not need all these parts, so expect there to be some left over depending upon the specification of your TV.


This product is intended for indoor use only. Use of this product outdoors could lead to failure and personal injury.

It is the responsibility of the installer to ensure that the mounting wall is of a suitable standard and void of any services (eg gas, electricity, water etc).


AVF accept no responsibility for any damage or loss caused by installing this product in a sub standard wall.

Boxed Parts











Measure the TV fixing holes Width and Height





If width (X) is greater than 200mm or height (Y) greater than 200mm STOP installation now and contact the customer help line.



You are provided with 3 diameters of TV fixing screws, **M4**, **M6** and **M8**. Determine the screw diameter that fits and remember for step 3.

2 Preparing the TV Mounting Plate

Use the option that fits your TV

OPTION 1

- (X) 50mm x (Y) 50mm
- (X) 75mm x (Y) 75mm
- (X) 100mm x (Y) 100mm

OPTION 2


- (X) 100mm x (Y) 200mm
- (X) 200mm x (Y) 100mm

OPTION 3


X 200mm x **Y** 200mm

If in any doubt please call the customer help line

OPTION 1 75 mm 50 mm 100 mm 50mm Top 75mm 100mm (x)D



Example shown is 200 x 200 fixings




3 Fitting the TV Mounting Plate


No Spacers

For TVs with flat / unobstructed back.


Spacers G1/G2


For TVs with irregular / obstructed back.







WARNING













After completing step 3 you will have fittings left over, please keep for future reference.





Attach the bracket to the back of your TV using suitable screw, reducer and spacer combinations.

Solid Wall

Wood Stud










Ensure bracket is in the centre of the wood stud




55mm (21/8")



5 Connecting the TV

Attaching and Locking



Optional

TV Levelling

