


jl.avfgroup.com

466526 rev02

JNL204



20kg
44lbs



Read through **ALL** instructions before commencing installation.


If you have any questions about this product or issues with installation, contact the customer services help line before returning this product to the store.

CUSTOMER SERVICES HELP LINE NUMBER: 0333 320 0463


AVF Group Ltd. Hortonwood 30, Telford, Shropshire, TF1 7YE, England

Assembly Overview


Fit the TV Mounting Plate




Fit the Wall Bracket




Connect the TV



Suitable Wall Types



Solid Wall



Wood Stud


Tools Recommended








Stud Finder



Ø10mm (25/64")
Masonry



Ø3mm (1/8")
Wood



Index

1 Measure the TV fixing holes Width and Height

2 Removing the TV Mounting Plate

3 Preparing the TV Mounting Plate

4 Fitting the TV Mounting Plate

5 Fitting the Wall Bracket

6 Assemble the Bracket

7 Fitting the Wall Covers

8 Connecting the TV

9 Cable Management

Retain all packaging in case the bracket needs to be returned.

Contents may vary from photography/ Illustrations.




You will not need all these parts, so expect there to be some left over depending upon the specification of your TV.

This product is intended for indoor use only. Use of this product outdoors could lead to failure and personal injury.

It is the responsibility of the installer to ensure that the mounting wall is of a suitable standard and void of any services (eg gas, electricity, water etc).

AVF accept no responsibility for any damage or loss caused by installing this product in a sub standard wall.


Boxed Parts



TV Screws, Reducers and Spacers




K1 x4 **K2** x4 **M1** x4 **M2** x4




L1 x4 **L2** x4 **L3** x4 **L4** x4 **L5** x4 **L6** x4 **L7** x4 **L8** x4

1 Measure the TV fixing holes Width and Height



If width (X) is greater than 200mm or height (Y) greater than 200mm
STOP installation now and contact the customer help line



M4 = L1/L2


M5 = L3/L4

M6 = L5/L6

M8 = L7/L8

You are provided with 4 diameters of TV fixing screws, **M4**, **M5**, **M6** and **M8**. Determine the screw diameter that fits and remember for step 3.

2 Removing the TV Mounting Plate



3 Preparing the TV Mounting Plate

Use the option that fits your TV

OPTION 1

- (X) 50mm x (Y) 50mm
- (X) 75mm x (Y) 75mm
- (X) 100mm x (Y) 100mm

OPTION 2


- (X) 100mm x (Y) 200mm
- (X) 200mm x (Y) 100mm

OPTION 3

- (X) 200mm x (Y) 200mm



If in any doubt please call the customer help line

OPTION 1




If your TV fixing holes match any of the sizes shown above you will not need to use any adaptors. Please go to step 3.

OPTION 2





OPTION 3



Example shown is 200 x 200 fixings

Top




I x8 **J** x8

4 Fitting the TV Mounting Plate


No Spacers

For TVs with flat / unobstructed back







Spacers **M1/M2**

For TVs with irregular / obstructed back




WARNING




After completing step 4 you will have fittings left over, please keep for future reference

OPTION 1





OPTION 2 & 3





5 Fitting the Wall Bracket

Solid Wall






Remove Dust from Hole

Wood Stud



Ensure bracket is in the centre of the wood stud



N x3


O x3



Lubricate screw thread with soap



DO NOT overtighten screws.
Tighten screws by hand only



N x3




Lubricate screw thread with soap




DO NOT overtighten screws.
Tighten screws by hand only

6 Assemble the Bracket

i



ii




i

Firmly push part **E** with an even steady force (do not use a hammer) until part **E** has slid into position and enough thread is showing to attach parts **F**, **G** and **H**


7 Fitting the Wall Covers

i




Carefully bend apart the 2 highlighted sections shown above and then slide into position

ii




8 Connecting the TV

Attach TV




TV Locking




9 Cable Management




Ensure cables don't restrict arm movement




i



ii




iii




Check all fittings are tight

Optional

Lock tilt



TV Levelling



Storing the Allen Key

