

M4 = J1/J2

M5 = J3/J4

M6 = J5/J6

M8 = J7/J8

</


Securing to Furniture or Wall?

You can secure your TV to furniture or to the wall, decide how you will secure your TV and follow the appropriate steps.

Securing to Furniture - Follow steps 2,3 & 4


You can secure your TV to your furniture in 2 ways.

Clamp Method




Or


Screw Method




Securing to Wall - Follow steps 2,3 & 5




2 Assemble the TV Safety Bar



3 Attach to TV



WARNING




Attach the bracket to the back of your TV using suitable screw and reducer combinations

i After completing step 3 you will have fittings left over, please keep for future reference

4 Securing to Furniture

Clamp Method



Screw Method

