



TV Screws, Washers and Spacers



Attach the bracket to the back of your TV using suitable screw, washer and spacer combinations.

Illustration is for example only.
Your bracket and TV holes may differ.

If spacers are supplied with your TV you must use them instead of the spacers shown.

