
www.avfgroup.com

469102 rev00





Read through ALL instructions before commencing installation.

If you have any questions about this product or issues with installation, contact the customer services helpline before returning this product to the store.


Installation video guide and TV Height Calculator tool at myTVmount.com


UK-based support team:


0333 320 0463

Phone lines open Mon-Fri during AVF office hours









Index

- Measure the TV fixing holes Width and Height
- Preparing the TV Mounting Plate
- Fitting the TV Mounting Plate
- Fitting the Wall Bracket
- Fitting the Wall Bracket Covers
- 6 Hanging the TV
- **7** Fitting the Cable Management
- Tilt Adjustment
- 9 TV Levelling

Retain all packaging in case the product needs to be returned.


Contents may vary from photography / illustrations.

You will not need all these parts, so expect there to be some left over depending upon the specification of your TV.


This product is intended for indoor use only. Use of this product outdoors could lead to failure and personal injury.

It is the responsibility of the installer to ensure that the mounting wall is of a suitable standard and void of any services (eg gas, electricity, water etc).

AVF accept no responsibility for any damage or loss caused by installing this product in a substandard wall.




Measure the TV fixing holes Width and Height





If width (X) is greater than 200mm or height (Y) greater than 200mm STOP installation now and contact the customer help line.



You are provided with 3 diameters of TV fixing screws **M4**, **M6** and **M8**. Determine the screw diameter that fits and remember for step 3.

2 Preparing the TV Mounting Plate

Use the option that fits your TV

OPTION 1

X 50mm x Y 50mm

(X) 75mm x (Y) 75mm

(X) 100mm x (Y) 100mm

OPTION 2

(X) 100mm x (Y) 200mm


(X) 200mm x (Y) 100mm


OPTION 3

X 200mm x **Y** 200mm


If in any doubt please call the customer helpline

OPTION 1





Example shown is 200 x 200 fixings




3 Fitting the TV Mounting Plate


No Spacers

For TVs with flat / unobstructed back.





For TVs with irregular / obstructed back.







WARNING













After completing step 3 you will have fittings left over, please keep for future reference.

Attach the bracket to the back of your TV using suitable screw, reducer and spacer combinations.




Solid Wall

Wood Stud





↓10mm (25/64")









Ensure bracket is in the centre of the wood stud



\ Remove Dust from Hole.

75mm (3")





₽ 8



_ Lubricate screw thread with soap.



DO NOT overtighten screws. Tighten screws by hand only.

















DO NOT overtighten screws. Tighten screws by hand only.


5 Fitting the Wall Bracket Covers




6 Hanging the TV



Locking the TV




7 Fitting the Cable Management



8 Tilt Adjustment

Adjust screws to achieve perfect tilt resistance if required.



9 TV Levelling

