
jl.avfgroup.com

# **470210** rev00

## **JAK101**







Read through <u>ALL</u> instructions before commencing installation.

If you have any questions about this product or issues with installation, contact the customer services helpline before returning this product to the store.

CUSTOMER SERVICES HELPLINE NUMBER: 0333 320 0463

Retain all packaging in case the product needs to be returned.


Contents may vary from photography / illustrations.


You will not need all these parts, so expect there to be some left over depending upon the specification of your TV.


This product is intended for indoor use only. Use of this product outdoors could lead to failure and personal injury.

It is the responsibility of the installer to ensure that the mounting wall is of a suitable standard and void of any services (eg gas, electricity, water etc).


AVF accept no responsibility for any damage or loss caused by installing this product in a substandard wall.








## Measure the TV fixing holes Width and Height






If width (X) is greater than 800mm or height (Y) greater than 400mm STOP installation now and contact the customer help line.

You are provided with 4 diameters of TV fixing screws, **M4**, **M5**, **M6** and **M8**. Determine the screw diameter that fits and remember for step 3 or 8.




## **Mounting Your Soundbar**


Please use the illustration below to decide which steps you will need to use to Mount your Soundbar. For example, if you are mounting your Soundbar on a TV Bracket below your TV you would use steps **7**, **8**, **9**, **10** and **11**.











F

0

G




## **Mounting Above**


## No Spacers

For TVs with flat / unobstructed back.


Spacers K1/K2


For TVs with irregular / obstructed back.







#### **WARNING**













After completing step 3 you will have fittings left over, please keep for future reference.

Attach the bracket to the back of your TV using suitable screw, reducer and spacer combinations.




If you have a Samsung TV with Samsung Wall Mount Adapters you will have to use Screw **L10**. You may need to use Washer **K3** to ensure Brackets **B1/B2** are fitted securely.



Wall Mount Adapter


Attach your TV Bracket to the 4 fixing points you created in step3



The brackets and screws etc shown in grey are only an example. These are supplied by the TV wall bracket manufacturer.

## **5** Attaching Shelf Brackets

**Mounting Above** 

















Adjust part A to the depth of your Soundbar



Attach part **E** and then remove backing paper







x8




## **Mounting Below**


## No Spacers

Spacers K1/K2


For TVs with flat / unobstructed back.


For TVs with irregular / obstructed back.







#### **WARNING**













After completing step 8 you will have fittings left over, please keep for future reference.

Attach the bracket to the back of your TV using suitable screw, reducer and spacer combinations.




If you have a Samsung TV with Samsung Wall Mount Adapters you will have to use Screw **L10**. You may need to use Washer **K3** to ensure Brackets **B1/B2** are fitted securely.



Wall Mount Adapter


Attach your TV Bracket to the 4 fixing points you created in step 8



The brackets and screws etc shown in grey are only an example. These are supplied by the TV wall bracket manufacturer.

## **Attaching Shelf Brackets**

**Mounting Below** 


















Adjust part A to the depth of your Soundbar






# Solid Wall

Wood Stud









— Remove Dust from Hole.

70mm (2¾")

\$mm (5/16")













DO NOT overtighten screws. Tighten screws by hand only.





















## 13 Attaching Soundbar

