


471832 Rev01

Please read these instructions thoroughly before installation.



**60kg
132lb**

If you have any questions or need
spare parts don't worry, we're happy to help.

Customer Helpline

0333 320 0463

Helpline Open Mon to Thurs 9am - 5pm, Fri 9am - 4pm

Online Support

www.avfgroup.com/support

AVF Group Ltd. Hortonwood 30, Telford, Shropshire, TF1 7YE, England

WARRANTY INFORMATION

LIFETIME WARRANTY

AVF warrants that the product is free from defects in material and workmanship, as long as the product is owned by the original consumer purchaser. If, during the stated warranty of this product, it proves to be defective, AVF will remedy the defect by either repairing or replacing the defective part or, replacing the entire product. Proof of original purchase is required and should be retained.

AVF reserve the right to substitute replacement products to others of similar value and design (Usually in the event of discontinued product models).

AVF accept no responsibility for failures / loss which result from misuse, negligence, accident, improper assembly or installation or other causes beyond AVF's reasonable control and also excludes and will not pay any incidental and consequential damages.



PLEASE REVIEW ALL NOTES AND PRODUCT INSTRUCTIONS BEFORE COMMENCING THE INSTALLATION.

INSTALLATION: This product is sold as a home DIY product and as such, it is the responsibility of the installer to ensure that the product is correctly installed. AVF accept no responsibility if the product is incorrectly installed.

This product is intended for indoor use only. Use of this product outdoors could lead to failure and personal injury.

IF YOU ARE IN ANY DOUBT, CONSULT A QUALIFIED CONTRACTOR.

NOTES

WALLS: It is the responsibility of the installer to ensure that the wall is of a suitable standard and void of any services (eg gas, electricity, water etc). AVF accept no responsibility for any damage or loss caused by installing this product in a sub standard wall.

WALL FIXINGS: Wall fixings are supplied for wood, brick, solid masonry and also, for some specific products, fixings are supplied for fixing to plasterboard.

DO

- Retain all packaging in case the bracket needs to be returned.
- When fastening to wood studs, be sure to pre-drill holes into the wood stud.
- When fastening to brick or solid masonry, drill the holes in accordance with the instructions. Always remove drill dust from the hole before inserting the wall plug.
- Wall plug body must be fully inserted into the wall (ie fully into the brick).
- Lubricate the wall screws with soap to ease installation.
- Check the strength of the installation before fitting the TV.
- Periodically check strength of installation, signs of corrosion, damage or loose components.

DON'T

- Do not set in mortar joints.
- Do not over tighten screws.

TV HANGING

Must be carried out using the manufacturers threaded holes intended for this purpose. All variables of TV hanging screws are supplied within the product box (Because of the universal nature of this product, expect to have excess parts left over following your installation).

It is the responsibility of the installer to ensure the correct TV hanging screws are selected. If in doubt consult the TV manufacturer. AVF accept no responsibility for any damage caused by the use of the incorrect TV hanging screw or the use of incorrect fixing holes.

Index

1 Measure the TV fixing holes Width and Height

2 Preparing the TV Mounting Plate

3 Fitting the TV Mounting Plate

4 Fitting the Wall Bracket

5 Connecting the TV

Retain all packaging in case the product needs to be returned.

Contents may vary from photography / illustrations.






You will not need all these parts, so expect there to be some left over depending upon the specification of your TV.

This product is intended for indoor use only. Use of this product outdoors could lead to failure and personal injury.


It is the responsibility of the installer to ensure that the mounting wall is of a suitable standard and void of any services (eg gas, electricity, water etc).

AVF accept no responsibility for any damage or loss caused by installing this product in a substandard wall.


Tools Recommended




Stud Finder



Suitable Wall Types




Solid Wall




Wood Stud


Boxed Parts



A



B



C x4




D x8



E x8



F x16



G x4

TV Screws, Reducers and Spacers



H1 x4



H2 x4




I1 x8




I2 x4




J1 x4




J2 x4




J3 x4




J4 x4




J5 x4




J6 x4




J7 x4




K x3



L x3

1**Measure the TV fixing holes Width and Height**

If width **a** is greater than 400mm or height **b** greater than 400mm
STOP installation now and contact the customer helpline.



Determine which diameter TV Screws
fit your TV and put them to one side.

M4, M6 or M8

We will select the correct length later.

2 Preparing the TV Mounting Plate

Use the option that fits your TV.


OPTION 1

- (X) 75mm x (Y) 75mm
- (X) 100mm x (Y) 100mm
- (X) 200mm x (Y) 100mm
- (X) 200mm x (Y) 200mm

When attaching adaptors **C** you must always use **HOLES x4** and either of the **SLOTS**.


OPTION 2

- (X) 75mm - 400mm (Y) 75mm - 400mm









Before you fully tighten the TV mounting plate check that the mounting plate holes line up with the fixing holes on the back of your TV.

OPTION 1



OPTION 2

Adaptors **C** can be fixed in different positions in the slots on Plate **B** to match your TV fixing holes.




3

Fitting the TV Mounting Plate

No Spacers


For TVs with flat / unobstructed back.







Spacers

11/12

For TVs with irregular / obstructed back.




WARNING





After completing step 3 you will have fixings left over, please keep for future reference.

Attach the bracket to the back of your TV using suitable screw, reducer and spacer combinations.






Solid Wall






Remove Dust from Hole.

Wood Stud



Ensure bracket is in the centre of the wood stud



Lubricate screw thread with soap.





DO NOT overtighten screws.
Tighten screws by hand only.



x3



x3



x3



Lubricate screw thread with soap.




DO NOT overtighten screws.
Tighten screws by hand only.


DO NOT use wall plugs in a
wood stud wall.

5 Connecting the TV

Attaching and Locking



TV Levelling



Optional

Lock tilt

