






463577 rev05

Swift Mount
TV WALL MOUNTS



Swift Mount, PO Box 340, Telford, TF1 9DS, UK
Swift Mount, AVF Inc., 2775 Broadway, Cheektowaga, Buffalo, New York, 14227, USA

2

Top
Haut
Parte Superior

A_{x4}
M4 x 16mm

B_{x4}
M5 x 16mm

C_{x4}
M6 x 16mm

D_{x4}
M8 x 16mm

E_{x4}
M5

F_{x4}
M6

G_{x4}

TV

TV

A+E
B+E
C+F
D

A+E+G
B+E+G
C+F+G
D+G

3

65mm (2 9/16")

Remove dust from hole
Retirez la poussière du trou
Elimine el polvo del agujero

Ø8mm (5/16")

Lubricate screw thread with soap
Lubrifiez le pas de vis avec du savon
Lubrique la rosca del tornillo con jabón

F_{x2}
M6

H_{x2}

I_{x2}

3

50mm (2")

Ensure bracket is in the centre of the wood stud
Assurez-vous que l'applique est au centre de la latte de bois
Asegúrese de que el soporte está en el centro de la viga de madera

Ø3mm (1/8")

TV

F_{x2}
M6

H_{x2}

4

i

Click!

ii