

2

Top

Select fixings for your TV

T1-T8

T9

If Required **T10**

T11/T12

Top

M4/M5 **T1-T4**

M6 **T5/T6**

M8 **T7/T8**

T9

T10

If required **T11/T12**

T11/T12

T11/T12

T11/T12

TV **X**

TV **✓**

TV **X**

TV **✓**

3

Solid Wall

Top

i

65mm (2 9/16")

12.5mm (1/2") Max

ii

Remove dust from hole

iii

Lubricate screw thread with soap

W1x2

W2x2

3

Wood Stud

12.5mm (1/2") Max

50mm (2")

Top

i

ii

Ensure bracket is in the centre of the wood stud

iii

Lubricate screw thread with soap

W1x2

4