







You can slide your TV horizontally by small amounts if required
Vous pouvez glisser légèrement votre téléviseur horizontalement si nécessaire
Puedes deslizar tu TV horizontalmente poco a poco si lo necesitas



This technical drawing illustrates a double-arm wall mount for a television. It consists of a vertical mounting plate on the left, which is attached to a wall. Two horizontal arms extend from the plate, each featuring a series of oval-shaped cutouts for height adjustment. The arms are connected to a TV bracket on the right, which is designed to hold the television. The drawing shows the assembly in a perspective view, highlighting the adjustable nature of the arms.



AVF Group Ltd. Hortonwood 30, Telford, Shropshire, TF1 7YE, England
AVF Group, Inc. 2775 Broadway, Cheektowaga, Buffalo, New York, 14227 USA
www.avfgroup.com

1

Top
Haut
Parte Superior

B1

B2

✓

✗

T1x4

M4
16mm

T2x4

M4
30mm

T3x4

M5
16mm

T4x4

M5
30mm

T5x4

M6
16mm

T6x4

M6
30mm

T7x4

M8
16mm

T8x4

M8
30mm

T9x4

M5

T10x4

M6

T11x4

T12x8

✗

TV

T1-T4&T9

T5/T6&T10

T7/T8

✓

TV

T1-T4&T9&T12

T5/T6&T10&T12

T7/T8&T12

TV

2

↑UP

65mm (29/16")

✓

✗

Remove dust from hole
Retirez la poussière du trou
Elimine el polvo del agujero

Lubricate screw thread with soap
Lubrifiez le pas de vis avec du savon
Lubrique la rosca del tornillo con jabón

W3x4

M6

W2x4

W1x4

2

↑UP

50mm (2")

Ensure bracket is in the centre of the wood stud
Assurez-vous que l'applique est au centre de la latte de bois
Asegúrese de que el soporte está en el centro de la viga de madera

✓

TV

W3x4

M6

W1x4

3

↑UP

↓

↑

W3x4

M6

W1x4