

TNEL200B-1 **4270339**



STOPPEN



**EMBALLAGE ET
FILM PLASTIQUE**



À JETER

Etablissements Darty & fils ©, 129 Avenue Gallieni, 93140 Bondy, France

Boxed Parts / Pièces empaquetées / Onderdelen in doos

 T5 x4	 T4 x4	 T3 x4	 T2 x4	 T1 x4
 W5 x2	 W4 x2	 W3 x2	 W2 x2	 W1 x2



Retain all packaging in case the bracket needs to be returned. Contents may vary from photography/illustrations.

You will not need all these parts, so expect there to be some left over depending upon the specification of your TV.

This product is intended for indoor use only. Use of this product outdoors could lead to failure and personal injury.

It is the responsibility of the installer to ensure that the mounting wall is of a suitable standard and void of any services (eg gas, electricity, water etc).

Darty Plc accept no responsibility for any damage or loss caused by installing this product in a standard wall.

Periodically check all nuts and bolts are tight.

