

2

Superior / Topo

Top

Y 75 100 150 200

X 75 100 150 200

(mm)

Superior Topo

T1x4
M4 x 16mm

T2x4
M5 x 16mm

T3x4
M6 x 16mm

T4x4

T5x4

X

T1/T2/T3

T4

T5

TV

3

55mm (2 1/8")

Top

12.5mm (1/2") Max

Quite el polvo del agujero
Retire o pó do orifício

Ø8mm (5/16")

W1x2

W2x2

Lubrique la rosca del tornillo con jabón
/ Lubrifique a rosca com sabão

3

50mm (2")

12.5mm (1/2") Min

Ø3mm (1/8")

W1x2

Lubrique la rosca del tornillo con jabón
Lubrifique a rosca com sabão

4

Diagram 4 illustrates the process of mounting the bracket to the back of the TV. The top part shows the bracket being aligned with the mounting holes on the back of the TV frame. The bottom part shows the bracket being secured with screws. A screwdriver is shown inserting a screw into one of the holes. A warning icon (two people) is present in the top right corner.