


jl.avfgroup.com



466527 rev01 ###

JAK101



13.6kg
30lbs



Read through ALL instructions before commencing installation.

If you have any questions about this product or issues with installation, contact the customer services help line before returning this product to the store.

CUSTOMER SERVICES HELP LINE NUMBER: 0333 320 0463

AVF Group Ltd. Hortonwood 30, Telford, Shropshire, TF1 7YE, England

Retain all packaging in case the bracket needs to be returned.
Contents may vary from photography/ Illustrations.
You will not need all these parts, so expect there to be some left over depending upon the specification of your TV.
This product is intended for indoor use only. Use of this product outdoors could lead to failure and personal injury.
It is the responsibility of the installer to ensure that the mounting wall is of a suitable standard and void of any services (eg gas, electricity, water etc).
AVF accept no responsibility for any damage or loss caused by installing this product in a sub standard wall.

Tools Recommended

Ø8mm (5/16")
Masonry

Ø3mm (1/8")
Wood

Stud Finder

Suitable Wall Types

Solid Wall

Wood Stud

Boxed Parts

A

B1



B2

C


D

E


O



1 Measure the TV fixing holes Width and Height



If width **(X)** is greater than 800mm or height **(Y)** greater than 400mm
STOP installation now and contact the customer help line





M4 =	L1-L3
M5 =	L4
M6 =	L5-L7
M8 =	L8-L10

You are provided with 4 diameters of TV fixing screws, **M4**, **M5**, **M6** and **M8**. Determine the screw diameter that fits and remember for step 3 or 10.



Mounting Your Soundbar

Please use the illustration below to decide which steps you will need to use to Mount your Soundbar. For example, if you are mounting your Soundbar on a TV Bracket below your TV you would use steps **9, 10, 11, 12** and **13**.


Soundbar




SONOS Playbar



i




ii


**F** x8**G** x8

No Spacers





For TVs with flat / unobstructed back

Spacers **K1/K2**


For TVs with irregular / obstructed back




WARNING



After completing step 3 you will have fittings left over, please keep for future reference



Example shown is 400 x 400 fixings




Attach the bracket to the back of your TV using suitable screw, reducer and spacer combinations

4 Attaching TV Mount

Mounting Above



Attach your TV Bracket to the 4 fixing points you created in step 3



The brackets and screws etc shown in grey are only an example. These are supplied by the TV wall bracket manufacturer.

5 Attaching Shelf Brackets

Mounting Above





H x4 **I** x4


6 Attaching Soundbar

Mounting Above


- i Adjust part **A** to the depth of your Soundbar



- ii Attach part **E** and then remove backing paper




- iii








7 Attaching SONOS playbar adaptor

Mounting Above




8 Attaching SONOS playbar

Mounting Above





You must use locking screw **P**x2

i



ii


**F** x8**G** x8

10 Fitting the TV Brackets

Mounting Below


No Spacers

For TVs with flat / unobstructed back







Spacers **K1/K2**


For TVs with irregular / obstructed back




WARNING



After completing step 10 you will have fittings left over, please keep for future reference



Example shown is 400 x 400 fixings




Attach the bracket to the back of your TV using suitable screw, reducer and spacer combinations

11 Attaching TV Mount

Mounting Below


Attach your TV Bracket to the 4 fixing points you created in step 10



The brackets and screws etc shown in grey are only an example. These are supplied by the TV wall bracket manufacturer.

12 Attaching Shelf Brackets



Mounting Below




13 Attaching Soundbar

Mounting Below


i Adjust part **A** to the depth of your Soundbar



ii Attach part **E** and then remove backing paper





iii



14 Attaching SONOS playbar adaptor

Mounting Below








H x4

I x4



15 Attaching SONOS playbar

Mounting Below






You must use locking screw **Px2**

Solid Wall






Remove Dust from Hole

Wood Stud



Ensure drill marks are in the centre of the wood stud



Lubricate screw thread with soap

DO NOT overtighten screws.
Tighten screws by hand only




M

x4

N

x4



Lubricate screw thread with soap



DO NOT overtighten screws.
Tighten screws by hand only



M



x4

Solid Wall






Remove Dust from Hole

Wood Stud





Ensure drill marks are in the centre of the wood stud



Lubricate screw thread with soap

DO NOT overtighten screws.
Tighten screws by hand only




Lubricate screw thread with soap

DO NOT overtighten screws.
Tighten screws by hand only


18 Attaching Soundbar

Mounting Above or Below


- i Adjust part **A** to the depth of your Soundbar



- ii Attach part **E** and then remove backing paper



- iii



19 Attaching SONOS playbar

Mounting Above or Below

